

Low temperature oxidation catalysis for Diesel engine emission control by FT-IR

Fanny Colinot, Frédéric Meunier and Marco Daturi

Laboratoire Catalyse et Spectrochimie, ENSICAEN, Université de Caen, CNRS, 6 Bd Maréchal Juin, F-14050 Caen, France

Introduction

Forthcoming regulations dealing with the protection of the environment together with rocketing fossil fuel prices are pushing for better engine efficiencies. In this respect, Low Temperature Combustion (LTC) systems are currently receiving a lot of interest. However, these systems require new exhaust gas treatment catalysts able to oxidise relatively high concentrations of CO and residual hydrocarbons at low temperatures, while the NO present should preferably not be oxidised to NO₂. The new catalytic materials must be durable under the severe post-combustion conditions (e.g. high temperature spikes, high steam concentration) and should contain the lowest possible amount of expensive noble metals.

In the present study, *operando* infrared (IR) spectroscopy was used to investigate under realistic conditions the oxidation activity of Pt and Pd supported on different oxides, with the aim of generating mechanistic information that will be used for the design of improved formulations.

Experimental Sample preparation

Five different high surface area supports kindly supplied by Rhodia $(Al_2O_3, CeO_2, Ce_{0.50}Zr_{0.50}O_2, Zr_{0.92}Pr_{0.08}O_{2-8}$ and a mixed oxide $Zr_{0.77}CeO_{0.17}Nd_{0.04}La_{0.02}O_{2-8}$, noted MO, for the sake of brevity) were impregnated with Pt and Pd precursors.

Each support was stabilised by a thermal pre-treatment before the impregnation (0.8% wt). Subsequently, the samples were calcined and finally submitted to a hydrothermal treatment at 973 K in order to simulate catalyst ageing.

In situ IR study: dispersion calculations by CO adsorption

Metal dispersion was measured following the method described by Binet et al. on Pd supported compounds.1 Selfsupported disks of the samples were treated in an IR quartz cell, first by an oxidising cleaning treatment up to 873K, then by a reducing treatment under H_2 at 473 K to improve the metal particle affinity for CO. Calibrated small amounts of CO were then introduced into the cell, measuring in parallel the area of the IR bands associated with the adducts. Spectra were recorded with a Nicolet 6700 FT-IR (Fourier Transform Infrared Spectroscopy) spectrometer and treated by the Nicolet OMNIC[™] software.

Operando study

The catalyst was investigated under conditions similar to that occurring in LTC catalytic converters using a dedicated apparatus with various gas supplies and analytical systems. Details concerning the lay-out and the characteristics of this so-called *operando* system are reported in Reference 2. A schematic representation of the system is shown in Figure 1.

Similarly to the case of the *in situ* analyses, the catalysts were studied by FT-IR spectroscopy in a reactor cell; the analysis of the outlet gases was performed by means of a FT-IR gas microcell and a mass spectrometer.

The samples were exposed to a reaction flow representative of a Diesel exhaust, made of: 0.1% CO, 300 ppm NO, 10% CO₂, 200 ppm H₂, 100 ppm decane, 8% O₂, 1% H₂O and 100 ppm of a mix (50/50) of propane/propene.

Argon was used as the carrier gas for a total flow of $25 \text{ cm}^3 \text{min}^{-1}$. The exposure of the sample to the reaction flow was carried out by successive steps of 20 min at different temperatures from 373 K to 673 K.

Results and discussions *In situ* IR study: dispersion calculations by CO adsorption

The interaction of CO with metal atoms is generally described using the model proposed by Blyholder^{3,4} based on molecular orbitals. Through metal back-donation effects, the v(CO) vibration is sensitive to: (i) the number of metal atoms linked to CO molecules; (ii) the coordinance of the metal atom onto which the CO is adsorbed; (iii) the degree of oxidation of the metal; (iv) the surface coverage; and (v) the presence of electrophilic or nucleophilic compounds.

The methodology chosen in order to measure the metal dispersion is based on the hypothesis (verified by CO adsorption studies followed by IR measurements) that carbon monoxide preferentially adsorbs on the accessible surface metal atoms and that there is a *ca* 1:1 ratio between the number of surface metal atoms and adsorbed CO molecules.

CO is observed on the support only after the saturation of the metallic phase and no residual gas pressure can be detected in the cell, therefore all the CO molecules introduced until the metal surface is saturated are considered as adsorbed on the catalyst.





Figure 1. Schematic representation of the *operando* system (top) and the IR reactor cell (bottom).

CO adsorption on supported Pd The spectra corresponding to the CO adsorption on different Pd-supported materials present similar features, independently from the nature of the supporting oxide. An example is given in Figure 2 for Pd/CeO₂. Different bands can be observed in the spectral range of the v(C-O) vibration stretching mode.

The most intense band at 2062 cm⁻¹ (idicated by "It") corresponds to CO linearly adsorbed on Pd located on terraces of the Pd crystallites. A shoulder can be observed near 2030 cm⁻¹ (idicated by "Ie"), due to the CO adsorption on Pd atom located on the edges of the Pd crystallites. At lower wavenumbers 1923, 1845 and 1724 cm⁻¹, broad bands are attributed to doubly- and triply-bridged CO (II–III).

When the CO coverage increases, an increase of the frequency is observed (2077, 1948, 1869 and 1776 cm⁻¹). The greater the number of adsorbed CO molecule, the lower is on average the electron back-donation from the metal to the adsorbates. The back-donation decrease leads to a weakening of the adsorbate-metal bond and to a strengthening of the CO bond, therefore to an increase of the CO stretching wavenumber.⁵

Bands below 1600 cm^{-1} show the presence of carbonate species. CO can in fact also interact with the basic O^{2-} sites of the support and form successively carbonite CO_2^{2-} and carbonate CO_3^{2-} ions.⁶ Taking into account that these bands are weak and that the molar extinction coefficient of carbonate is nearly 10-fold greater than that of CO, the transformation of CO into carbonates can be neglected.

CO adsorption on supported Pt

The spectra obtained in the case of CO adsorption on the Pt-containing oxides were similar to those obtained in the case of the Pd-containing catalysts. One main band, corresponding to v(CO) vibration of linearly adsorbed CO on the Pt atoms (on terraces and edges), is observed after CO adsorption on the five different Pt supported catalysts. Bridged CO species give rise to a weak feature at around 1800 cm⁻¹.

Calculation of the metal dispersion

The variation of the integrated intensity of the ν (CO) bands bound to the metal plotted as a function of the amount of introduced CO exhibits a slope break





Figure 2. Surface IR spectra of a Pd/CeO₂ sample exposed to the adsorption of calibrated CO doses.

corresponding to the saturation of the accessible metal sites on the surface.

Assuming that the adsorption ratio CO/Metal atom can be considered as 1 (as mentioned above), the number of surface palladium sites nM^* (equal to the number of adsorbed CO at metal saturation) can be easily determined.

The dispersion can be then calculated according to the following equation:

dispersion =
$$\frac{nM*}{nM_{impregnated}}$$

in which $nM_{impregnated}$ is the total number of metal atoms impregnated. This gives values between 5% and 30% depending on the support and on the metal, Pd being relatively better dispersed than Pt. The dispersion values are low due to the severe ageing treatment.

Operando IR study: analysis of the oxidation properties of the materials under stream

The different samples were studied under a gas stream representative of the car exhaust to be treated. At each temperature, IR spectra of the catalyst surface and of the corresponding gas phase were recorded at the steady state, alongside the mass spectra of the reactor effluent, which was continuously monitored. The combination of the three analytical methods allowed us (i) to discriminate and quantify the different species coordinated to the surface of the samples and (ii) to measure the concentration of the various reaction products in the gas phase. An example of the typical features obtained by these methods is reported in Figure 3 for Pd/CeO₂. From these spectra we can determine:

- on the surface, the evolution of the hydroxyl groups and adsorbed water in the 3800–3000 cm⁻¹ region; the adsorbed hydrocarbons in the 3000– 2700 cm⁻¹ interval; the acetates and carbonates (1700–1000 cm⁻¹) produced by the partial or total oxidation of organic compounds and CO. The signal corresponding to CO₂ in the gas phase present near the wafer can also be detected between 2400 cm⁻¹ and 2300 cm⁻¹;
- in the gas phase, we can distinguish the presence of water vapour, hydrocarbons, carbon dioxide, carbon monoxide and nitrogen monoxide, as indicated in the figure.

It must be stressed that the gas-phase concentrations measured by IR were consistent with those obtained by mass spectrometry. Both gas-phase signals are actually complementary, since the IR data can resolve some difficulties associated with important common mass fragments (e.g. m/z = 28, 44).

Carbonates were formed at the lowest temperatures in the presence of large CO_2 concentrations. Hydrocarbons started to be converted generally at 373K and remained observable in the IR surface spectra up to 523K. The conver-

sion of hydrocarbons gave rise to acetates. The intensity of acetates increased up to 473 K, while that of hydrocarbon decreased, and decreased at higher temperatures. Meanwhile, carbonates remain adsorbed, the intensity of the band associated with these adsorbed species becoming lower with the temperature. CO oxidation also takes place in the 373–573 K temperature range.

The CO conversion profiles showed that the sample exhibiting the lowest CO light-off temperature (~400K) was Pd/ $Zr_{0.92}Pr_{0.08}O_{2-\delta}$, which also showed a total carbon monoxide conversion at 473K. (Catalyst light-off temperature is defined as the temperature at which 50% conversion of CO is achieved.) Such activity values are close to the requirements expected for this post-combustion treatment. Pd/Al₂O₃ exhibited a similar behaviour, but about 100K higher in the light-off domain, without presenting total CO conversion up to 673K. Since alumina presents significant acidity, the possibility of surface coking seems the most likely. Pt-containing samples showed a lower oxidising power. In the best case conversion started above 423K. The lightoff temperatures were between 470K and about 570 K, while the total CO conversion was achieved only for the $Pt/Ce_{0.50}Zr_{0.50}O_2$ sample, at 623K. The main reason for that should probably be found in the fact that at low temperature CO poisons Pt sites, as it was evidenced by IR spectra of the sample surface, showing intense carbonyl





Figure 3. FT-IR spectra of a Pd/CeO₂ sample submitted to the reaction flow at different temperatures (surface spectra, top; corresponding gas phase, bottom).

bands up to \sim 473K (spectra not shown here).

Regarding the oxidation of hydrocarbons, the supports based on rare-earth oxides seemed to yield better oxidising properties than alumina, certainly due to the high oxygen mobility of these compounds.⁷ It is important to note that no traces of aldehydes or other oxygenated or polluting by-products were detected.

Conclusions

Various catalysts based on platinum and palladium supported on basic metal oxides and solid solutions containing rare-earth elements were investigated in the study described here.

A concentration of the noble metals as low as 0.8% was sufficient to obtain

a satisfactory CO oxidation rate, without the formation of noxious products, such as NO_x or aldehydes. Currently, the rare-earth-based compounds (that on praseodymium, in particular) seem to be most interesting for this type of exhaust gas control application. The analytical techniques combined here, i.e. mass spectrometry, *in situ* and *operando* IR spectroscopy, yield a very powerful method for studying in detail this type of catalyst, under realistic conditions, in order to gain mechanistic information that will allow tailoring an improved active and selective catalyst.

Acknowledgement

The authors acknowledge the kind contribution of PSA company to this study.

References

- 1. C. Binet, A. Jadi and J.C. Lavalley, *J. Chim. Phys.* **86**, 451 (1989).
- 2. T. Lesage, C. Verrier, P. Bazin, J. Saussey and M. Daturi, *Phys. Chem. Chem. Phys.* **5**, 4435 (2003).
- B.J. Blyholder, J. Phys. Chem. 68, 2772 (1964).
- 4. B.J. Blyholder, *J. Phys. Chem.* **79**, 756 (1975).
- 5. P. Bazin, O. Saur, J.C. Lavalley, M. Daturi and G. Blanchard, *Phys. Chem. Chem. Phys.* **7**, 187 (2005).
- 6. J.C. Lavalley, *Catal. Today* **27**, 377 (1996).
- F. Mariño, C. Descorme and D. Duprez, *Appl. Catal. B: Environmental* 54, 59 (2004).